

CHEVRON

COLLECTION

INSTALLATION INSTRUCTIONS



Mikasa[®]
REAL WOOD FLOORS

INSTALLATION INSTRUCTIONS FOR MIKASA REAL WOOD FLOORS – CHEVRON COLLECTION

The Mikasa Chevron Collection is best installed through nailing, stapling, and gluing down. It can also be installed as floating, but more precautions should be taken like gluing the connections and adding support on the floor to reduce the movement of the strips.

MIKASA PRISTINE – 15mm

This product may be installed:

- In rooms, above or below ground level.
- Over plywood, OSB, concrete subfloors, or directly over existing hard surfaces.

This product may be installed over a radiant heating system, if:

- The floor is NOT made with Jatoba or Maple hardwood. These wood types must not be used with radiant heating systems.
- The installation conforms to Mikasa Special Instructions for installation over radiant heat. Detailed installation procedures are described in our installation guide. Download it directly from www.mikasafloors.com

The secret of a successful Mikasa Chevron floor installation is measurement accuracy and subfloor preparation. It is advisable to use extremely accurate measurements of the room and layout for the best results. During the installation process, it is advisable to validate measurements as you lay out the strips to make necessary adjustments. All measurements are to be calculated by the metric system for accurate and seamless installations.

INSTALLER'S / OWNER'S RESPONSIBILITY

Since wood is a natural product, it contains inherent variations in colour, grain, appearance, and other visual imperfections. Mikasa floors are manufactured as per industry standards which permits a defect tolerance not exceeding 5%. These defects may be a result of the manufacturing or naturally occurring characteristics of the material. It is recommended that a 5% cutting or grading allowance should be added to the total square footage when calculating the quantity of required flooring.

NOTE: SPECIAL INSTRUCTIONS FOR INSTALLATION OVER RADIANT HEAT ARE MENTIONED IN THIS BROCHURE. THESE INSTRUCTIONS APPLY ONLY TO THOSE PRODUCTS OF FLOORING THAT ARE SPECIFICALLY APPROVED FOR USE OVER RADIANT HEAT AND MEET THE CONDITIONS GIVEN ABOVE. INSTALLATION OF NON-APPROVED PRODUCTS OR INSTALLATION OF APPROVED PRODUCTS IN A NON-APPROVED MANNER, OVER RADIANT HEATING SYSTEMS WILL VOID THE PRODUCT WARRANTY.

This product should NOT be installed in bathrooms or laundry rooms.

It is the sole and joint responsibility of the installer and owner to conduct a quality inspection of all pieces of Mikasa flooring before installation. Any piece of flooring that appears to contain a manufacturing defect should not be installed. Flooring that has been installed will be deemed to have been inspected and accepted by the installer and owner, even if the owner is not present at the time of installation. If a defect is found, please contact your dealer.

It is the sole responsibility of the installer to ensure that the job site, subfloor, and installation tools and materials meet or exceed all applicable industry standards.

Mikasa accepts no responsibility for problems arising from incorrect or improper site preparation or installation procedures. Check local building codes and bylaws before commencing installation to ensure compliance with local requirements. In the event of a discrepancy between local codes and manufacturer's guidelines, local codes should be followed.

Very important: Mikasa floors are made from wood and wood-based products, and like any wood product they will react to changes in the environment. Please pay special attention to site conditions, subfloor, expansion space, temperature, and humidity levels.

SITE PREPARATION

INSTALLATION IN A NEWLY CONSTRUCTED HOME

Installation of flooring is one of the last jobs while constructing a home. Before you install your Mikasa Real Wood Floor, ensure that:

- The building is completely enclosed with all doors and windows in place, including the door from an attached garage to the interior of the house.
- All concrete, masonry, plastering, drywall, texturing, painting, and other wet work is complete and dry.
- Basements and crawlspaces are dry; crawlspaces must have no standing water but must also have a vapour barrier and adequate ventilation under local building codes. Gutters and downspouts are in place, directing water away from the building.
- HVAC systems are fully operational, enabling heat and humidity levels to be controlled and maintained throughout the structure.
- Subfloor is properly prepared for installation.

While installing over radiant heat, ensure that the system is in full working order, has been fully tested and is running for a minimum of two weeks before installation. The system should be turned off for 24 hours before installation in the install zone.

INSTALLATION IN AN EXISTING HOME (RENOVATION)

Installation in an existing home must meet the same conditions as in a new home. If part of a larger remodeling project, ensure that all wet work (painting, wallpapering, texturing, etc.) is complete and thoroughly dry before commencing installation of the floor.

IN ADDITION:

- Remove all furniture, artwork, and other valuables from the installation area.
- Remove skirting and profiles.
- Undercut door casings (use a piece of flooring as a depth gauge).
- Remove existing flooring, if necessary (carpets and underlay must be removed, but most of the Mikasa floors with glue-free locking joint systems can be installed directly over most other flooring types, including sheet or tile vinyl, ceramic, parquet, etc. Ask your dealer in case of any doubt).
- If installing over radiant heat, it is strongly recommended that a radiant heat technician be consulted before installation. All to ensure that the heating system can be operated effectively at temperatures acceptable to Mikasa flooring. The system should be turned off in the install zone 24 hours before installation. (Download installation instructions for underfloor heating and thermal conductivity from www.mikasafloors.com)

CLIMATE CONTROL

Conditions at the job site must be maintained between 65°-75°F (18°-24°C) and humidity at 35-55% before, during, and after the installation. The flooring material should not be delivered to the job site until these conditions have been met and maintained for one week prior to installation, if installing over a wood subfloor and two weeks, if installing over concrete. Following installation, these conditions should be maintained at all times to ensure proper performance of the floor.

When temperature and humidity have met the conditions detailed above, the material may be delivered to the job site. While stacking the boxes, cross-stack to ensure good airflow between layers. Do not lay boxes directly on concrete subfloors; elevate them on blocks. Do not open the boxes; leave them closed until conditions are perfect for installation, then open as and when needed.

SUBFLOOR PREPARATION

Like many home-improvement projects, one of the most critical parts of installing Mikasa flooring is to make sure the surface is properly prepared before installing the product. So, take the time to do this step completely and thoroughly. The installer and customer are jointly and solely responsible for ensuring that the subfloor is suitable for flooring and properly prepared for installation.

All subfloors must be clean, dry, structurally sound, and flat by 1/8" in 8' (or 3mm in 1m). Plywood subfloors must meet local building code requirements [US: minimum 3/4"(19mm) T&G plywood or 23/32" (18mm) T&G OSB. Canada: minimum 5/8" (16mm) T&G plywood or 3/4"(19mm) T&G OSB)]. They must be secure to the joints, free of squeaks and protruding fasteners.

MOISTURE CONTENT

All subfloors must be tested for moisture content according to NWFA guidelines, and the moisture content of both subfloor and flooring must be within allowable limits before commencing installation. The moisture content of plywood or OSB subfloor must not exceed 12%. The moisture content of the flooring must be within 4 percentage points of the subfloor.

Concrete subfloors must be fully cured (60 days) before installation. The moisture content of the slab should not exceed 3lb/1000 sq./ft/24 hours.

If the flooring is being installed over a radiant heating system, the moisture content of the slab should not exceed 2lb/1000 sq./7 ft/24 hours. The system should be turned off in the installation zone for 24 hours before installation begins and left off for the duration of the installation period.

COLOUR RACKING

Mikasa flooring being a natural product contains natural variations in colour and has grainy patterns. To prevent colour "grouping" or repetitive grain patterns in the finished floor, it is recommended that boards be racked (visually sorted) before installation to create a satisfactory and pleasing colour arrangement. Immediately prior to installation, unpack 1 or 2 cartons to get a sense of the range of colour variation and arrange the planks to achieve a satisfactory appearance.

While racking, inspect all boards for visible manufacturing defects. Boards with manufacturing defects exceeding the industry standards (5% of total quantity) may be replaced by the dealer under the terms of the product warranty. Once installed, boards will be considered to have been accepted by the customer and will not be eligible for replacement. (See warranty for details.)

EXPANSION SPACE

Mikasa Real Wood Floors will expand and contract with changes in ambient temperature and humidity. To allow for this, during installation, leave a 3/8" (10mm) expansion space around the entire perimeter of the floor between the flooring and walls.

Also, leave some space between the flooring and any vertical obstacle, such as stairs, pipes, door sills, tiles, cabinets, etc.

Note: In climates with extreme variations in humidity (beyond the range of 35 to 55%), or large installations 75+ sqm (800+ ft), a larger expansion space may be required.

If installing the floor in a room measuring more than 30 ft (10m) by floorboard width, or more than 30 ft (10m) measured by board length, leave an expansion gap in the center of the space and cover it with an expansion profile (T-cap). The gap should be wide enough to allow 3/8" (10mm) expansion space on each side of the T-cap base. An expansion gap and T-cap should be used in any door threshold where the flooring is being carried through into an adjoining room.

SPECIAL INSTRUCTIONS FOR INSTALLATION OVER RADIANT HEAT

If installing over radiant heat, place approved heat sensors on the subfloor following Mikasa Special Instructions.

- The floor must be able to move freely - do not connect or install close to any construction part.
- Rooms with off square areas like L, F, T, U-shapes, separate the areas with an expansion joint and especially always in door openings.
- For installation over radiant heat, a minimum of 5 sensors must be placed for every 1000 sq. ft of flooring installed. (Download the installation instructions for radiant heating and thermal conductivity from www.mikasafloors.com.)

VAPOUR BARRIER & UNDERLAY

If the flooring is being installed on a concrete subfloor, over a crawlspace, or below ground level, a vapour barrier must be installed. An underlay that reduces impact sound & vapour must be laid under the planks. For example, use Mikasa VAPROTECT or moisture barrier and underlay/felt paper as an intermediate layer. Seal the seams with duct tape along their entire length. Leave an excess of 4" (100mm) of sheeting extending up the wall at all outer edges and hold in place with blue or painter's masking tape. (This excess will be trimmed away later.)

STARTING WALL

For best results, Mikasa Real Wood Floors should be installed with the boards running parallel to incoming sunlight. When you have determined which direction the flooring will run, decide where you want to start from — usually the longest wall adjacent to the wall with windows. It is important that the flooring is installed in perfectly straight rows parallel to the starting wall. To verify that the starting wall is straight, measure out 12 inches (300mm) from each end of the wall and snap a chalk line parallel to it. Measure the distance from the line to the wall every 2 or 3 ft (600-900mm). If it is consistent, the wall is straight. If there is a variance anywhere of more than a quarter inch (7 mm), you may need to trim the edge of the first row of floorboards to match the shape of the wall.

INSTALLATION

TOOLS AND MATERIALS REQUIRED

1. Approved and suggested adhesive by Mikasa
2. Adhesive manufacturer's recommended trowel
3. Tape measure
4. Chalk line
5. Straight edge
6. Expansion shims
7. Floor protectors
8. Hammer
9. Wood saws



PATTERN DIRECTION

Mikasa Chevron flooring may be installed with reference to any room landmark, but it is very important to consider the orientation of the site such as:

- The longest direction of the room, or
- Major architectural landmarks, like the main entrance hall, a wall with window, or fireplace.

STEP 1


- 1.1 Snap chalk line (Y) through the center of the room as shown in Fig. 1.1. Next, determine the perpendicular line (X). Important: Line X must be exactly 90° to line Y to perfectly form a square corner.




- 1.2 To ensure this angle:

A) From center point (a) of line Y, measure about 100mm along line Y and mark point (b) (Fig. 1.2A).

B) From center point (a) measure 75mm in the general direction of where line X will be and scribe an arc (Fig. 1.2B).



C) Return to original 100mm mark (b) on the line Y and measure 125mm, scribing an arc crossing 75mm arc from the previous step (Fig. 1.2C).




D) Verify all measurements before proceeding.

E) If correct, snap chalk line through the intersection of arcs and center point of line Y. Chalk line represents line X and should form 90° angle with line Y as shown in Fig. 1.1.


STEP 2

- 2.1 Cut starter board from plywood 15/18mm thickness x 550mm x 550mm. The starter board must be perfectly square. Use this piece of plywood to make a starter/backer board which will be very handy to start the first row of strips.
- 2.2 Align top and bottom corners of starter/backer board with line Y and secure to floor (Fig. 3) by nailing the starter/backer to the subfloor. Leave the nail sticking out a bit for easy removal.
- 2.3 Dry-lay two to three rows (for procedure refer to Step 3) to determine distance from A to B (Fig. 3). Once the distance is determined, snap another chalk line to represent guidelines A and B. Begin installation in the center of the room, aligning one corner backer board with guidelines A and B and securing it to the subfloor. Place one strip on each side of the backer board to ensure measurement accuracy, then remove.
- 2.4 Continue to lay-up with the next row as in Fig.4. You can use the starter/backer board as a guideline and determine the next row's alignment.




STEP 3

- 3.1 Continue installing in this manner, alternating installation with left-handed and right-handed boards, until starting area is completely installed.
- 3.2 Place weight on boards and let the adhesive set up properly (refer to adhesive supplier recommendation).
- 3.3 Remove starter board and complete installation as described above. Snap new guidelines as needed.



POST INSTALLATION

Remove expansion shims and use required Mikasa solid wood moldings and/or trim pieces to cover expansion space. Always nail moldings to the wall, never to flooring. Nailing the moldings on the floor will obstruct the expansion and contraction of the wood floor.



CLEAN UP

Immediately clean any adhesive spilled on wood flooring during installation.

MAINTENANCE

Clean the floor using a dry dust mop or damp (lightly misted or well rung out) mop or cloth. Regularly use KLUMPP or BONA Wood Floor Cleaner for best results. Do not use oil soap or water emulsion, self-polishing waxes. Never wet mop the floor. Place peel & stick floor protectors on furniture legs to prevent damage. See Mikasa Floor Care Guide & Maintenance procedure on www.mikasafloors.com.

- When using acoustic underlayment, it must be glued down over the subfloor before gluing down strips using the same recommended adhesive.
 - Extremely precise strip milling may require the use of tapping block for better tongue and groove fit.
 - Row to row installation requires that no glue seeps into grooves at any time for perfect tongue and groove fit.
- Avoid getting adhesive on your hands to minimize clean-up. Wipe any adhesive from the floor right away, using solvent and towels. Use paint thinner or lighter fluid to remove stubborn adhesive spills.

To maintain strips in place and avoid strip movement causing gapping during installation, use 3M blue adhesive tape.



www.mikasafloors.com



Download Mikasa App    |  | 

info@mikasafloors.com | To know more, call on toll free no.: 1800-833-0004